



Front Plate Carrier.



Front Plate Carrier


Strap to open flap.
Same for Rear Flap

Top Portion of flap folds
into this pocket

Cummerbund Quick Release Buckles



Front Plate Carrier Front Flap Open



Front Plate Carrier Quick Release Mechanism.




Rear Plate Carrier



Rear Plate Carrier Rear Flap Open



Rear Plate Carrier Cumberbund attached with Hanger system.



Cummerbund Front and Rear



Side Plate Pocket



Rear Plate Carrier Body side.



Pocket for plate hangs inside internal carrier where insert is placed

Rear Plate Carrier Inside Insert Pocket





These straps are to secure the rear shoulder pads under the front shoulder pads.

Attachment points




Plate and Insert pocket

Front Plate Carrier Body Side



Front Plate Carrier Body Side Inside Plate/Insert Pocket



Front Plate Carrier Body Side Inside Plate/Insert Pocket