

Extended Cold Weather Clothing...

FORMULA FOR REPELLING WATER



Every time you wash your extended cold weather clothing system (ECWCS) parka and trousers, you wash away more than just dirt. You wash away some of their water repellency.



So, if your ECWCS has gone through lots of washing and rainwater no longer beads on the fabric surface, it's time to restore the water repellent protection. If your post laundry does that job, take your parka and trousers there. A field or post laundry can get five gallons of water-repellent laundry additive with NSN 8030-01-408-9444, or 55 gallons with NSN 8030-01-408-9445.



IF YOU'RE
RESPONSIBLE FOR
RESTORING THE
ECWCS WATER
REPELLENCY, YOU'LL
NEED TO GO
THROUGH SUPPLY.

Units can order a case of 24 8-oz bottles of additive with NSN 8030-01-408-9446.

Or you can order any of the following three brands of additive directly from the manufacturer: Stormshed, Xpel or Protex 2000. Any one will do a good job.

Get Stormshed from:

Evergreen Specialties, Inc.
Suite 277
4521 PGA Blvd
Palm Beach Gardens , FL
33418-3997
Phone: (877) 330-8760
Fax: (800) 834-1809
Email: sales@
evergreenspecialties.com

Get Xpel from:

Caled Chemical
26 Hanes Drive
Wayne, NJ 07470
Phone:(800) 652-2533
Fax: (800) 225-3332
Email: gpg102@aol.com

Get Protex 2000 from:

M & M Technologies, Inc.
4001 Kennett Pike, # 134
PO Box 4092
Wilmington, DE 19807
Phone: (800) 658-5958
Fax: (302) 658-3734
Email: pmoodys@dol.net

GREAT! NOW
I KNOW WHERE
TO GO... I'LL
BE BACK IN A
MINUTE.



OK, I'VE GOT
THE WATER
REPELLENT...
NOW WHAT?



LAUNDRY

ONCE YOU
HAVE THE WATER
REPELLENT,
HERE'S HOW TO
RESTORE THE
PROTECTION...

- Wash the ECWCS in your washing machine according to the care label instructions.
- After you've run your clothing through the entire wash cycle, run them through the rinse cycle again to make sure all the soap is rinsed out.
- Set the machine again to the wash cycle and the water temperature to warm. Fill the machine until all clothing is completely covered with water.



—Two ounces of repellent for a parka or a pair of trousers if you're treating them separately.

—Three ounces of repellent if you're treating them together.

- Continue the wash cycle until it's finished. Your wet clothes may have a white film. That's the repellent. It won't show after they dry.
- Tumble dry the ECWCS on permanent press and at medium heat until dry.



WHERE
ARE YOU
GOING WITH
THAT BLOW-
TORCH?

NOW THAT I
CAN RESTORE
WATER
REPELLENCY,
I'M GONNA
SEE IF I CAN
THAW OUT
OL' WALT!

P.S. END